

# Sapphire Instruments Co., Ltd.

## Calibration Procedure of SI-9071

1. How to open the case, please follow the steps.

1.1 Remove the battery lid.

1.2 You will see the two screws and loosen them.



Fig. 1

1.3 Near the BNC cable side, there are two protuberant mortises. Use fingers to push back and pull upward.



Fig. 2

1.4 Use fingers to press the bottom case inward, and pull it backward and upward.




Fig.3

1.5 Hold the bottom case and push back (to input lines direction).



Fig.4

1.6 You will see the two metal cases. There is one screw on the PCB. Loosen it, then the whole metal case can be taken out. There are two wires still connected with the upper case. Leaves them there.



Fig. 5

1.7 The metal case is illustrated as follows:




Fig. 6

2. Explanation of adjustment point. Please refer to Fig. 7.

- (1) SW1: Switch for selecting attenuation ratio.
- (2) SW2: Power switch.
- (3) VR4: Variable resistor for adjusting offset when SW1 at attenuation 1/100.
- (4) VR2: Variable resistor for adjusting offset when SW1 at attenuation 1/10.
- (5) VR1: Variable resistor for adjusting low frequency CMRR.
- (6) VR3: Variable resistor for adjusting accuracy.
- (7) VC1: Variable capacitor for adjusting square wave compensation and high frequency CMRR.
- (8) VC2: Variable capacitor for adjusting square wave compensation.
- (9) CON1: Power jack for connecting to 6VDC power adapter.




Fig. 7


### 3. Adjustment Procedure:

This procedure is for use by qualified service personnel to adjust SI-9071 properly. The equipment's required are listed in Table 1.

No.	Item	Minimum Requirements
1	Power Supply	6VDC/500mA or 9VDC/300 mA mains adaptor or 4xAA cells
2	DMM	DC Accuracy < 0.5%
3	Function Generator	Maximum Frequency > 10MHz Sine-wave Distortion < 1%
4	Sine wave Signal Source	600Vpp, 60Hz sine wave 200Vpp, 20kHz sine wave
5	Oscilloscope	Bandwidth >= 20MHz Accuracy <= 2%

Table 1

Please connect a 6 VDC power adaptor to CON1, and turn SW2 on to warm up for 10 minutes. Then follow the steps below.



### 3.1 Offset Adjustment:

- a. Referring to Fig. 8, connect both input lines together.
- b. Connect output BNC connector to a DMM.
- c. Put SW1 at attenuation 1/10.
- d. Adjust VR2 to make output voltage approach to zero as small as possible.
- e. Put SW1 at attenuation 1/100.
- f. Adjust VR4 to make output voltage approach to zero as small as possible.
- g. Repeat “c” to “g” steps until output voltage is always within  $\pm 5$  mV at either “e” or “g” step.




Fig. 8

### 3.2 Square Wave Adjustment:

- a. Referring to Fig. 9, connect output BNC to the oscilloscope which has good grounding.
- b. Set the output of the function generator to 20Vp-p, 10kHz square-wave.
- c. Connect the red input line to a 20Vp-p, 10 kHz square wave signal lead and the black input line to ground lead.
- d. Put SW1 at attenuation 1/10.
- e. Set the VOLTS/DIV switch on oscilloscope's panel to 0.1V at attenuation 1/10 and the TIME/DIV switch to 200 us.
- f. Adjust VC1 to make the displayed waveform become as Fig 10(b).
- g. Connect the black input line to 20 Vp-p, 10 kHz square wave signal lead and the red input line to ground lead.
- h. Adjust VC2 to make the displayed waveform become as Fig. 10(b).




Fig. 9




Fig. 10

### 3.3 Low Frequency CMRR Adjustment

- a. Referring to Fig. 11, connect output BNC to the oscilloscope which has good grounding.
- b. Set the output of the Sine wave signal source to 600Vp-p 60 Hz sine-wave
- c. Put SW1 at attenuation 1/10.
- d. Set the VOLTS/DIV switch on oscilloscope's panel to 1mV and the TIME/DIV switch to 2ms.  
Then a 60 Hz sinusoid waveform should be displayed on the screen.
- e. Adjust VR1 to make the amplitude of displayed waveform as small as possible. Finally, the amplitude should be less than 3.5 mVp-p (after excluding noise).




Fig. 11

### 3.4 High Frequency CMRR adjustment

- a. Referring to Fig. 12, connect output BNC to the oscilloscope has good grounding.
- b. Set the output of the Sine wave signal source to 200Vp-p 20kHz sine-wave
- c. Put SW1 at attenuation 1/10.
- d. Set VOLTS/DIV switch on oscilloscope's panel to 5mV and the TIME/DIV switch to 2ms.
- f. Adjust VC1 slightly to make the amplitude of displayed waveform as small as possible. Finally the amplitude should be less than 16 mVp-p (after excluding noise).




Fig. 12